

## NOTES:

- "SOIL STOP" CAN BE GARDENEDGE PERFORATED METAL EDGE RESTRAINT, PRECAST OR POURED-IN-PLACE CONCRETE CURBS, LANDSCAPE TIMBERS, ETC.
- IF GARDENDRAIN ELEMENTS ARE INSTALLED UNDER HARDSCAPE AREAS THE CUPS MUST BE FILLED WITH LIGHTWEIGHT EXPANDED AGGREGATE. GARDENDRAIN MAY ALSO BE USED AS FORMS FOR SETTING CONCRETE FOOTINGS FOR CURBS, ETC.
- REFER TO APPLICABLE MM 6125-FR ROOFING OR WATERPROOFING GUIDELINE DETAILS FOR PROPER MEMBRANE/FLASHING DETAILS AND ALTERNATIVES.



POSSIBLE TRANSITION OPTION

— GARDENEDGE —

(EXTENSIVE APPLICATION DEPICTED)

NO SCALE GA—5A