

NOTES:

- "SOIL STOP" CAN BE PERFORATED GARDENEDGE METAL EDGE RESTRAINT, PRECAST OR POURED—IN—PLACE CONCRETE CURBS, LANDSCAPE TIMBERS, ETC.
- ROCKCURB OR OTHER PRECAST CURBING MAY REQUIRE STABILIZING AGAINST DIFFERENTIAL LOADING. (e.g. PINNING END-TO-END, MORTARING IN PLACE, ETC.). CONSULT PROJECT ENGINEER.
- IF GARDENDRAIN ELEMENTS ARE INSTALLED UNDER HARDSCAPE AREAS THE CUPS MUST BE FILLED WITH LIGHTWEIGHT EXPANDED AGGREGATE. GARDENDRAIN MAY ALSO BE USED AS FORMS FOR SETTING CONCRETE FOOTINGS FOR CURBS, ETC.
- REFER TO APPLICABLE MM 6125-FR ROOFING OR WATERPROOFING GUIDELINE DETAILS FOR PROPER MEMBRANE/FLASHING DETAILS AND ALTERNATIVES.



POSSIBLE TRANSITION OPTION

- ROCKCURB
(EXTENSIVE APPLICATION DEPICTED)

NO SCALE

GA-5B